



Time Change for Daylight Saving

Nitsuko - DX series

To set the Clock/Calendar from a Multiline Terminal with an LCD screen

Can be done from any handset with a LCD screen

1. Press **SPEAKER**
2. Dial **828**
3. Dial **0000**
4. Dial **2 DIGITS** for the **YEAR**
5. Dial **2 DIGITS** for the **MONTH**
6. Dial **2 DIGITS** for the **DAY OF THE MONTH**
7. Dial **1 DIGIT** for the **DAY OF THE WEEK**
(Sun= 0 and Mon = 1 etc)
8. Dial **2 DIGITS** for the **HOUR in 24 hour time**
9. Dial **2 DIGITS** for the **MINUTES**
10. Press **SPEAKER**